IGT Gas Regulator Installation Guide



Model A126i-M003. Seven steps to fit the regulator on a household LPG cylinder in Nepal. No special tools: a flat screwdriver is enough.

Before you start

- Turn all stove knobs off.
- Keep flames, incense and cigarettes away.
- Open a window or door so air can move.

The 7 steps

1 Check the cylinder valve

Remove the plastic seal cap. Look at the black rubber ring inside the cylinder mouth. If the ring is cracked, hard or missing, do not fit the regulator; replace the ring first.

2 Fit the hose and clamps

Push the gas hose fully onto the regulator nozzle. Slide a clamp over the joint and tighten it with a screwdriver. Do the same at the stove end.

3 Mount the regulator

Check that the regulator lever is horizontal (OFF). Lift the black locking collar, place the regulator straight on the cylinder valve and push down until you hear a click.

> **Safety:** Keep the lever OFF while you mount the regulator.

4 Turn the lever ON

Turn the lever up to the vertical (ON) position.

5 Press the reset button

Press the reset button on the bottom of the regulator for 2 seconds. Gas now reaches the hose and the gauge needle rises.

6 Do the 60-second leak test

Keep the stove knobs off and watch the gauge needle. It must stay still for 60 seconds. If it slowly drops, turn the lever OFF, tighten the clamps and test again.

> **Safety:** Do not light any flame until the needle has stayed still for 60 seconds.

7 Light the stove

If the needle stayed still, the connection is sound. You can now light the stove.

If you smell gas

1. Turn the regulator lever OFF.
2. Open the windows and doors.
3. Do not light a flame or touch electric switches.
4. Call or WhatsApp us.

Need help?

If you get stuck, we guide you by phone or WhatsApp video.

9740849659 · WhatsApp

- Online guide and help request: igtnepal.com/installation
- Order the regulator: igtnepal.com/product/igt-gas-regulator
- 2-year replacement warranty: igtnepal.com/replacement